



[www.partyprorents.com](http://www.partyprorents.com)

# Electric Hot Box Instructions

**MACHINE MUST HAVE 110 OUTLET WITH 15-20 AMP BREAKER**

## Operations Instructions

1. Plug in machine
2. Turn to desired temperature
3. Make sure all doors are closed
4. Allow 15-20 minutes to get to desired temperature