



www.partyprorents.com

Coffee Maker Instructions

Operations Instructions

1. Place coffee maker on sturdy, level surface
2. Fill coffee maker with cold water to desired level
3. Plug coffee maker into outlet
4. Remove coffee grounds when done with use

Please rinse coffee maker before returning

NEVER IMMERGE COFFEE MAKER INTO WATER

Helpful Hints

Brewing time 30-60 cups is 60 minutes; 90-100 cups is 90 minutes

Coffee equivalents: 1 pound of coffee is equal to 4.75 cups of ground coffee

| Number of Cups | Coffee Measure |
|----------------|----------------|
| 30 | 2 cups |
| 55-60 | 3.5 cups |
| 90 | 6 cups |

***Machine operates best when plugged in on its own breaker
A 110 outlet is required to operate***