



www.partyprorents.com

Sno Cone Machine Instructions

**NEVER ALLOW ANY FOREIGN OR METALLIC OBJECTS AROUND
THE SHAVER AREA OF THE SNO-KING. ICE PICKS, SCOOPS, AND
DEBRIS THAT MAY BE IN THE ICE OFTEN DAMAGE BLADES**

The Sno-King can take ice cubes or block ice, if you break the block into pieces approximately 3" to 4" in size. The ice will not enter the shaving chute if the pieces are too large.

Operations Instructions

1. Fill the gooseneck to within an inch of the top with ice cubes or block ice (no larger than 3" to 4"). The larger the pieces, the better the snow
2. Toggle the POWER switch to the ON position
3. While pushing the MOTOR switch, apply downward pressure to the pusher handle. Apply firm and even pressure to make the best snow. Practice will allow you to gauge when to stop pressing. This allows the ice to reset against the shaver head. Too much pressure will result in snow that is coarse; too little pressure will make the snow mushy

***Machine operates best when plugged in on its own breaker
A 110 outlet is required to operate***